



Piper

Description	Part Number	Model
Bearing, Stabilator	CA452-394	PA28-151,161,181,236,201T,PA28R-201,201T,PA32-260,300,301,301T,PA32R-300,301,301T
Bearing, Stabilator	CA452-538	PA28RT-201,201T,PA32RT,PA34-200,200T,220T,PA44-180
Bulkhead, Front	W35323-012	PA28-151
Bulkhead, Rear	W587-330	PA28-151
Bulkhead Spinner	CA87325-010	PA28-161
Bumper, Nose Gear	CA79072-000	PA28-140,150,151,160,161,180,181,235,236,PA32-260,300,301,301T
Bushing	CA20737-040	PA31-300,325,350,PA31-350-T1020,PA31P,PA31P-,350,PA31T,1,2,PA42,PA42-720,1000
Bushing	CA453-903	PA31P-350
Bushing	CA63900-089	PA28R-180,200,201,201T,PA28RT-201,201T,PA32R-300,301,301T,PA32RT,PA34-200T,220T,PA44-180
Bushing	CA86102-104	PA31-300,310,325,350,PA31P,PA31P-350,PA31T,1,2
Bushing	CA86102-105	PA31-300,310,325,350,PA31P,PA31P-350,PA31T,1,2
Bushing	CA86102-106	PA31-300,310,325,350,PA31P,PA31P-350,PA31T,1,2
Bushing	CA95061-108	PA28-151,161
Bushing	NAS75-5-011	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-T1040,PA42-720,1000
Bushing	NAS75-6-011	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T,1,2,3-T1040,PA42-720,1000
Bushing	NAS75-7-011	PA31-300,PA31T-1,2,3-T1040,PA31P,PA31P-350,PA31-350-T1020,PA42-720,1000
Bushing	NAS75-7-014	PA31
Bushing	NAS76A3-004	PA34-200,200T,220T
Bushing	NAS76A3-019	PA34-200,200T,220T
Bushing	NAS76A3-023	PA34-200,200T,220T
Bushing	NAS77-10-094	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T-1,2,3-T1040
Bushing	NAS77-18-050	PA31P-350,PA42-720,1000
Bushing	NAS77-4-042	PA31T-1,2,3-T1040,PA31P,PA31P-350,PA31-350-T1020,PA42-720,1000
Bushing	NAS77-5-019	PA31-300,350,T1020,PA31P-350,PA31T-1,2,3-T1040
Bushing	NAS77-5-042	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T,1,2,3-T1040,PA42-720,1000
Bushing	NAS77-7-035	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-T1040,PA42-720,1000
Bushing	NAS77-7-038	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T,1,2,3-T1040,PA42-720,1000
Bushing	NAS77-7-040	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T,1,2,3-T1040,PA42-720,1000
Bushing	NAS77-7-068	PA31-300,PA31-350,PA31-350-T1020,PA31P-350,PA31T,1,2,3-T1040,PA42-720,1000
Bushing	NAS77-8-038	PA31P-350
Bushing	NAS77-8-044	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T-1
Bushing	NAS77-8-072	PA31P-350
Bushing	NAS77-8-084	PA31-300,PA31-350,PA31-350-T1020,PA31P,PA31P-350,PA31T-1
Bushing, Door Mech.	CA20737-044	PA31-300,310,325,350,PA31-350-T1020
Bushing, Door Mech.	CA41413-041	PA31-300,310,325,350,PA31-350-T1020
Bushing, Flap Hinge	CA63900-019	PA28-140,150,160,180,235,PA28R-180,200,201,201T,PA28RT-201,201T,PA32-260,300,301,301T,PA32R-300,301,301T,PA32RT,PA34-200,200T,220T,PA44-180
Bushing, Flap Roller	CA41413-005	PA31-300,310,350,PA31P,PA31P-350,PA31T-1,2
Bushing, Gear Housing	CA20737-023	PA31-300,310,325,350,PA31-350-T1020,PA31P,PA31P-350,PA31T,1,2
Bushing, Landing Gear	CA14843-016	PA24-180,250,260,400,PA28R-180,200,201,201T,PA30,PA32R-301,301T,PA32-300,PA32RT,PA34-200,200T,PA39
Bushing, Landing Gear	CA14843-018	PA24-180,250,260,400,PA30,PA39
Bushing, Main Gear	CA65003-041	PA28RT-201,201T,PA32R-301,301T,PA34-200,200T,PA44-180
Bushing, Main Gear	CA65003-044	PA28R-180,200,201,201T,PA28RT-201,201T,PA32R-300,301,301T,PA32RT,PA34-200,200T,PA44
Bushing, Main Gear	CA67026-012	PA34-200T,PA44-180
Bushing, Main Gear Fork	CA43256-002	PA31P,PA31P-350,PA31-300,310,325,350,PA31-350-T1020,PA31T,1,2,PA42-720,1000,PA42
Bushing, Main Gear Housing	CA43256-005	PA31P-350,PA31-300,310,325,350,PA31-350-T1020,PA31T,1,2
Bushing, Nose Gear	CA63900-109	PA28R-180,200,201,PA28RT-201,PA32R-300,301,301T,PA32RT
Bushing, Nose Gear	CA63900-122	PA28R-180,200,201,PA28RT-201,PA32R-300,301,301T,PA32RT
Bushing, Nose Gear	CA65003-046	PA28R-180,200
Bushing, Nose Gear	CA95061-133	PA32R-300,301,301T,PA32RT-300,300T
Bushing, Nose Gear Drag Brace	CA65003-045	PA28R-180,200,201,201T,PA28RT-201,201T,PA32R-300,301,301T,PA44-180
Bushing, Nose Gear Housing	CA40250-002	PA31-300,310,325,350,PA31-350-T1020,PA31P,PA31P-350,PA31T-1,2,PA42,PA42-720,1000
Bushing, Nose Gear Housing	CA43256-006	PA23-235,250,250(6),PA31P, PA31P-350,PA31-300,310,325,350,PA31-350-T1020,PA31T-1,2,3,T1040,PA42,PA42-720,1000
Bushing, Nose Gear Idler	CA20737-032	PA31-300,310,325,350,PA31P,PA31P-350,PA31T-1,2,PA42,PA42-720,1000
Bushing, Seat Roller	CA41413-038	PA23-235,250,PA24-260,PA25-150,235,PA31-300,310,325,350,T1020,PA31P,PA31P-350,PA31T-1,2,PA30,PA39,PA42-720,1000
Bushing, Steering	CA14976-102	PA30,PA31-300,310,325,350,PA31-350-T1020,PA39
Bushing, Torque Link	CA63310-000	PA28-140,150,151,160,161,180,181,235,236,201T,PA32-260,300,301,301T
Bushing, Torque Link	CA67026-007	PA28R-180,200,PA28RT-201,201T,PA32R-300,301,301T,PA32RT,PA34-200,200T,220T,PA44-180,PA46-310P,350P
Bushing, Torque Link	CA77780-005	PA38
Capacitor Assembly, Alternator	CA63897-006	PA28-140,151,180,181,R-200,RT-201,RT-201T, PA32-260,R-300,RT-300,301,R301,301T
Fastener	CA26246-000	PA24-180,250,260,PA30,PA32-260,300,301,PA32R-300,301,PA32RT-300,PA39
Filter & Gasket Kit	CA42370	PA23,PA23-160,250,250(6),PA24,PA24-250,260,PA28-140,151,161,150,160,180,181,PA38-112 PA28-235,236,PA32-260,PA44-180